

ATTACCHI SPECIFICI PER - SPECIFIC FITTING KIT FOR
 KIT DE MONTAGE SPECIFIQUE POUR - SPEZIFISCHER MONTAGEKIT FÜR
 ANCLAJE ESPECÍFICO PARA

OUTLOOK 2009
 125 - 150cc


ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS
 INSTRUCCIONES DE MONTAJE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE


1

NON INCLUSO
 NOT INCLUDED
 PAS INCLUS
 NICHT INKLUDIERT
 NO ESTA INCLUIDO
Q.TY n.-

2


SUPPORTO
 SUPPORT
 SUPPORT
 HALTERUNG
 SOPORTE
Q.TY n.2(Dx-Sx)


3

RONDELLA Ø8mm
 WASHER Ø8mm
 RONDELLE Ø8mm
 SCHEIBE Ø8mm
 ARANDELA Ø8mm
Q.TY n.2

4

VITE TBEI M6x30mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO
Q.TY n.4

5


BOCCOLA DI RITENZIONE Z1861
 PLASTIC BUSH
 DOUILLE PLASTIQUE
 PLASTIK BUCHSE
 CASQUILLO
Q.TY n.4

6

GOMMINO Z1858
 FAIRLEADER
 CHAUMARD
 GUMMI
 GOMA
Q.TY n.4

7

GOMMINO Z1857
 FAIRLEADER
 CHAUMARD
 GUMMI
 GOMA
Q.TY n.4

8

DISTANZIALE Z1862
 SPACER
 ENTRETOISE
 DISTANZSTUECK
 DISTANCIADOR
Q.TY n.4

9

DADO A.B. M6
 FLANGIATO
 BOLT M6
 ECROU M6
 MUTTER M6
 TUERCA M6
Q.TY n.4

